

# MEVO-TRACK-EVO-RT

\*Installation Instructions are applicable for other versions.

**WARNING – PLEASE READ ALL INSTRUCTIONS PRIOR TO INSTALLATION  
 READ AND FOLLOW ALL WARNINGS AND INSTRUCTIONS BEFORE INSTALLING OR MAINTAINING THIS PRODUCT.  
 TURN OFF POWER PRIOR TO ANY WORK ON THE SYSTEM OR PRODUCT.  
 DO NOT INSTALL DAMAGED PRODUCT.  
 AMBIENT TEMPERATURE AT LUMINAIRE LOCATION SHOULD NOT EXCEED 40°C DURING NORMAL OPERATION.**

Installing, wiring, and maintenance must be done by qualified persons or a certified electrician in accordance with all local and National Electrical Codes.

Warranty is voided in case of unauthorized modifications and/or improper use.

Save these instructions. Use as reference when service or maintenance is performed.

CAUTION – For Non – IC fixtures, do not install any fixture assembly closer than 6 inches (15.24cm) from any combustible material (insulation).

New Construction Mounting Plate driver compartments are rated for through wiring.

Refer to product label for voltage requirements and properly ground fixture in accordance with all local and national electrical codes.

If building and product supports optional dimming, connect dimming leads to dimming control system (provided by others). Refer to product label for dimming requirements. Isolate dimming wires individually if not in use.

Suitable for WET locations with lens only.



## ⚠️ WARNING ⚠️

- To avoid possible electrical shock, before installing light fixtures, disconnect power by turning off the circuit breakers both to the outlet box and to its associated wall switch location. If you cannot lock the circuit breakers in the off position, securely fasten a prominent warning device, such as a tag, to the service panel.
- Verify that supply voltage is correct by comparing it with the luminaire label information.
- Make all electrical and ground connections in the accordance with the National Electrical Code (NEC) and any applicable local code requirements.
- Wait for fixture and driver to cool before servicing and performing maintenance.

## ⚠️ CAUTION ⚠️

- All wiring must comply with national and local electrical codes and ANSI/NFPA 70. If you are unfamiliar with wiring, consult a qualified electrician.
- PPE Personal Protective Equipment such as gloves and safety glasses should always be used when installing, maintaining or servicing.
- Risk of fire. Keep combustible material away from fixtures.

## ⚠️ ADVERTENCIA ⚠️

- Para evitar un choque eléctrico, antes de instalar luminarias, desconecte la alimentación apagando los interruptores de circuito en el panel de servicio y en las paredes. Si no es posible bloquear los interruptores en la posición de apagado, sujete una etiqueta de seguridad en el panel de servicio.
- Compruebe que la tensión de alimentación es correcta comparándola con la información en la etiqueta de la luminaria.
- Haga todas las conexiones eléctricas y puesta a tierra de acuerdo con el código eléctrico nacional (NEC) y los requisitos del código local aplicable.
- Espere hasta que la luminaria y el controlador se enfrien antes de empezar el servicio y mantenimiento.

## ⚠️ PRECAUCION ⚠️

- Todo el cableado debe cumplir con los códigos eléctricos nacionales y locales y ANSI/NFPA 70. Si no está familiarizado con el cableado, consulte a un electricista.
- Al instalar, mantener o reparar, siempre se debe utilizar equipo de protección personal como guantes y lentes de seguridad
- Riesgo de incendio. Mantenga los materiales combustibles lejos de las luminarias.

## ⚠️ AVERTISSEMENT ⚠️

- Pour éviter les chocs, avant d'installer des appareils d'éclairage, coupez l'alimentation en désactivant les disjoncteurs et l'emplacement du commutateur mural. Si vous ne pouvez pas verrouiller les disjoncteurs en position d'arrêt, fixer un avertissement sur le panneau de service.
- Vérifiez que la tension d'alimentation est correcte en le comparant avec les informations d'étiquette de luminaire.
- Effectuer tous les raccordements électriques et mise à la terre dans la conformité avec le Code électrique National (NEC) et des exigences du code local applicable.
- Laisser suffisamment de temps pour l'appareil et pilote refroidir avant d'effectuer l'entretien et la maintenance.

## ⚠️ MIS EN GARDE ⚠️

- Tout le câblage doit être effectué conformément aux codes électriques locaux et nationaux et ANSI/NFPA 70. Si vous êtes peu familier avec câblage, vous devez utiliser un électricien qualifié.
- Équipement de protection personnelle comme des gants et des lunettes de sécurité doivent être utilisés en tout temps lors de l'installation, maintenance ou entretien.
- Risque d'incendie. Garder les matières combustibles loin de luminaires.





## VOLTAGE DROP TABLE

Power Supply	A Distance power supply/feed unit (2x1,5mm <sup>2</sup> - 2xAWG16)			
	5m [16.4']	10m [32.8']	20m [65.6']	30m [98.4']
(w)	B Track length with $\Delta V \leq 5.5\%$ (m) [ft]			
	(m) [ft]	(m) [ft]	(m) [ft]	(m) [ft]
60	50 [164']	50 [164']	50 [164']	50 [164']
96	50 [164']	50 [164']	40 [131']	25 [82']
260	35 [115']	20 [66']	n/a	n/a


IT-Le indicazioni sono relative ad un carico equivalente alla potenza erogata ed equamente distribuito sulla lunghezza indicata in tabella.  
 EN-Information refers to a load equivalent to the power supplied and equally distributed on the relevant length in the table.  
 FR-Les indications concernent une charge équivalente à la puissance fournie et uniformément distribuée sur la longueur indiquée dans le tableau.



Please ensure that the data bus wiring does not create a ring structure. **A failure-free data bus cannot be ensured if one is present.**  
 If the track installation requires the use of "L", "T" or "X" - shaped joint, it is possible to disconnect the data bus in these Joints to avoid creating a ring structures.




Power Supply





## MAX LOAD

MEVO - TRACK - SP  
 9500.../...-ST1-E; 9500.../...-ST6-E



MEVO - TRACK - RT & MEVO - TRACK - RTL  
 9500.../...-ST3-E; 9500.../...-ST8-E





## MEVO-TRACK-RT ST8-E

**MEVO-TRACK-RT  
1 - 9500-1/.../ST8-E**

TURN POWER OFF

60V dc Data BUS

Mechanical Key

CODE	L ft
9500-1/...-ST1-E	4'
9500-2/...-ST1-E	8'

**2 - USE**

Recessed (ceiling)

**3 - RECESSED FIXING**

MEVO-RC-T  
3a with spring S-9500/111

$> \varnothing$  wire

$\varnothing$  wire

**MAX LOAD**

25 Kg / 55 lbs

36 Kg / 79 lbs

48 Kg / 105 lbs

⚠ Check drywall max load!

$\varnothing$  4.5mm  
 $\varnothing$  0.18"


M4

**3**


**4**

**5**


$\oplus$   $T_c$  max:  
1 Nm / 0.7 lbs




6




7




7a




7b




7c




8




1




2




3




4





5





6








7





8




9

3c with aircraft suspension




1


MEVO-AC-S2  
9500-KIT1-...



2



3a



4 - IN ROW USE




S-9500/323-M6...





MEVO-AL-S2  
+  
9500-UIT2

1



4a



2


MEVO-L JOINT-RT  
5 - S-9511/...-ST8-E

MEVO-L JOINT-RT  
S-9511/...-ST8-E


MEVO-L FEED  
9518-S...

MEVO-L FEED  
9500-.../...-ST8-E  
(X2)

1




2





3

4


6 - CUTTING



1




2




In a continuing effort to offer the best product possible we reserve the right to change, without notice, specifications or materials that in our opinion will not alter the function of the product.


**MEVO-E FEED**  
7 - 9501-S/...-E




**8 - 90° ANGLE**




9 - ≠ 90° ANGLE





MEVO-FLEX-CON WITH 9518...





1




2



3




4




5


10 - WALL CEILING 90° ANGLE




MEVO-FLEX-CON WITH 9518...





1




2



3



4



5

In a continuing effort to offer the best product possible we reserve the right to change, without notice, specifications or materials that in our opinion will not alter the function of the product.